

# Cessna 172S Checklist

## PREFLIGHT INSPECTION

### CABIN

1. Pitot Tube Cover - REMOVE, check opening for blockage
2. Documents (AROW) - AVAILABLE IN THE AIRPLANE
3. Parking Brake - SET
4. Control Wheel Lock - REMOVE
5. Ignition Switch - OFF
6. Avionics Master Switch - OFF

### WARNING

When turning on the master switch, using an external power source, or pulling the propeller through by hand, treat the propeller as if the ignition switch were on. Do not stand, nor allow anyone else to stand, within the arc of the propeller, since a loose or broken wire or a component malfunction could cause the propeller to rotate. Hand propped starts are prohibited by CAPR 60-1.

7. Master Switch - ON
8. Fuel Quantity Indicators - CHECK QUANTITY and ENSURE LOW FUEL ANNUNCIATORS (L LOW FUEL R) ARE EXTINGUISHED
9. Avionics Master Switch - ON
10. Avionics Cooling Fan - CHECK AUDIBLY FOR OPERATION
12. Avionics Master Switch - OFF
13. Static Pressure Alternate Source Valve - OFF
14. Annunciator Panel Switch - PLACE and HOLD IN TST POSITION and ensure all annunciators illuminate
15. Annunciator Panel Test Switch - RELEASE. Check that appropriate annunciators remain on
16. Fuel Selector Valve - BOTH
17. Fuel Shutoff Valve - ON (Push full in)
18. Flaps - EXTEND

19. Pitot Heat - ON (Carefully check that pitot tube is warm to touch within 30 seconds)
20. Beacon, Nav, Strobe, Landing, Taxi, Pulse Lights - CHECK
21. Pitot Heat - OFF
22. Master Switch - OFF
23. Baggage Compartment – INVENTORY, SECURE CONTENTS  
Chocks, Pitot Tube Cover, Tow Bar, Ladder, First Aid kit, Survival Kit, Fuel Sampler, Cleaning Materials, 1 QT Oil, Landing/Taxi Light Bulbs, Avionics Control Lock.
24. Baggage Door – CHECK, Lock with Key

### EMPENNAGE

1. Rudder Gust Lock (if installed) - REMOVE
2. Tail Tie-Down - DISCONNECT
3. Control Surfaces - CHECK freedom of movement and security
4. Trim Tab - CHECK security
5. Antennas - CHECK for security of attachment and general condition

### RIGHT WING Trailing Edge

1. Aileron - CHECK freedom of movement and security
2. Flap - CHECK for security and condition

### RIGHT WING

1. Wing Tie-Down - DISCONNECT
2. Main Wheel Tire - CHECK for proper inflation and general condition
3. Fuel Tank Sump Quick Drain Valves - DRAIN small amount, check for water, sediment and proper fuel grade
4. Fuel Quantity - CHECK VISUALLY for desired level
5. Drained Fuel – RETURN uncontaminated fuel to tank
6. Fuel Filler Cap – SECURE and VENT UNOBSTRUCTED

### NOSE

1. Fuel Strainer Quick Drain Valve (bottom of fuselage) - DRAIN small amount, check for water, sediment and proper fuel grade

2. Engine Oil Dipstick/Filler Cap - CHECK oil level, then check dipstick/filler cap SECURE. Do not operate with less than 5 quarts. Fill to 8 quarts for extended flight
3. Engine Cooling Air Inlets - CLEAR of obstructions
4. Propeller and spinner - CHECK for nicks and security
5. Air Filter - CHECK for restrictions by dust
6. Nose wheel Strut and Tire - CHECK for proper inflation of strut and general condition of tire
7. Left Static Source Opening - CHECK for blockage

### **LEFT WING**

1. Fuel Tank Sump Quick Drain Valves - DRAIN small amount, check for water, sediment and proper fuel grade
2. Fuel Quantity - CHECK VISUALLY for desired level
3. Drained Fuel – RETURN uncontaminated fuel to tank
4. Fuel Filler Cap - SECURE
5. Main Wheel Tire - CHECK for proper inflation and general condition

### **LEFT WING Leading Edge**

1. Fuel Tank Vent Opening - CHECK for blockage
2. Stall Warning Opening - CHECK for blockage
3. Wing Tie-Down - DISCONNECT
4. Landing/Taxi Lights - CHECK for condition and cleanliness of cover

### **LEFT WING Trailing Edge**

1. Aileron - CHECK freedom of movement and security
2. Flap - CHECK for security and condition

### **BEFORE STARTING ENGINE**

1. Preflight Inspection - COMPLETE
2. Passenger Briefing - COMPLETE
3. Seats, Belts, Shoulder Harnesses - ADJUST and LOCK
4. Brakes - TEST and SET
5. Circuit Breakers - CHECK IN

6. Electrical Equipment, Autopilot (if installed) - OFF

### **CAUTION**

**THE AVIONICS MASTER SWITCH MUST BE OFF DURING ENGINE START TO PREVENT POSSIBLE DAMAGE TO AVIONICS**

7. Avionics Master Switch - OFF
8. Fuel Selector Valve - BOTH
9. Fuel Shutoff Valve - ON (Push full in)
10. Avionics Circuit Breakers - CHECK IN
11. Rotating Beacon - ON

### **STARTING ENGINE (With Battery)**

1. Throttle - OPEN 1/4 INCH
2. Mixture - IDLE CUT OFF
3. Propeller Area - CLEAR
4. Master Switch - ON
5. Auxiliary Fuel Pump Switch - ON
6. Mixture - ADVANCE until fuel flow starts to rise, then return to IDLE CUT OFF
7. Auxiliary Fuel Pump Switch – OFF

### **NOTE**

If engine is warm, omit priming procedure of steps 5, 6 and 7 above

8. Ignition Switch - START (RELEASE when engine starts)
9. Mixture - ADVANCE smoothly to RICH when engine fires

### **NOTE**

If engine floods, turn off auxiliary fuel pump, place mixture in idle cut off, open throttle 1/2 to full, and crank the engine. When engine fires, advance mixture to full rich and retard throttle promptly

10. Oil Pressure - CHECK
11. Navigation Lights - ON as required
12. Avionics Master Switch - ON

13. Radios - ON
14. Flaps - RETRACT

### **STARTING ENGINE (With External Power)**

1. Throttle - OPEN 1/4 INCH
2. Mixture - IDLE CUT OFF
3. Propeller Area - CLEAR
4. External Power - CONNECT to airplane receptacle
5. Master Switch - ON
6. Auxiliary Fuel Pump Switch - ON
7. Mixture - ADVANCE until fuel flow starts to rise, then return to IDLE CUT OFF
8. Auxiliary Fuel Pump Switch – OFF

#### **NOTE**

If engine is warm, omit priming procedure of steps 6, 7 and 8 above

9. Ignition Switch - START (RELEASE when engine starts)
10. Mixture - ADVANCE smoothly to RICH when engine fires

#### **NOTE**

If engine floods, turn off auxiliary fuel pump, place mixture in idle cut off, open throttle 1/2 to full, and crank the engine. When engine fires, advance mixture to full rich and retard throttle promptly

11. Oil Pressure - CHECK
12. External Power - DISCONNECT from airplane receptacle
13. Navigation Lights - ON as required
14. Avionics Master Switch - ON
15. Radios - ON
16. Flaps – RETRACT
17. Engine – LEAN for Taxi

### **TAXI**

1. Brakes - CHECK
2. Nose Wheel Steering - CHECK
3. Cross Wind Controls - APPLY

### **BEFORE TAKEOFF**

1. Parking Brake - SET
2. Passenger Seat Backs - MOST UPRIGHT POSITION
3. Seats and Seat Belts- CHECK SECURE
4. Cabin Doors - CLOSED and LOCKED
5. Flight Controls - FREE and CORRECT
6. Flight Instruments - CHECK and SET
7. Fuel Quantity - CHECK
8. Mixture - RICH
9. Fuel Selector Valve - RECHECK BOTH
10. Elevator Trim - SET for Takeoff
11. Throttle - 1800 RPM
  - a. Magnetos - CHECK (RPM drop should not exceed 150 RPM on either magneto or 50 RPM differential between magnetos)
  - b. Suction Gage – CHECK
  - c. Engine Instruments and Ammeter - CHECK
12. Annunciator Panel - ENSURE no annunciators are illuminated
13. Throttle - CHECK IDLE
14. Throttle - 1000 RPM or LESS
15. Throttle Friction Lock - ADJUST
16. Strobe Lights - AS DESIRED
17. Pulse Light - ON
18. Radios and Avionics - SET
19. Transponder - ALT
20. NAV/GPS Switch (if installed) - SET
21. Autopilot (if installed) - OFF
22. Wing Flaps - SET for Takeoff
23. Brakes - RELEASE

## **TAKEOFF**

### **NORMAL TAKEOFF**

1. Wing Flaps - 0°-10°
2. Throttle - FULL OPEN
3. Mixture – RICH (above 3000 feet, LEAN to obtain maximum RPM)
4. Elevator Control - LIFT NOSE WHEEL (at 55 KIAS)
5. Climb Speed – 70-80 KIAS

### **Short Field Takeoff**

1. Wing Flaps - 10°
2. Brakes - APPLY
3. Throttle - FULL OPEN
4. Mixture - RICH (Above 3000 feet, LEAN to obtain MAX RPM)
5. Brakes - RELEASE
6. Elevator Control - SLIGHTLY TAIL LOW
7. Climb Speed - 56 KIAS (Until all obstacles are cleared)

### **ENROUTE CLIMB**

1. Airspeed - 70-85 KIAS
2. Throttle - FULL OPEN
3. Mixture - RICH (Above 3000 feet, LEAN to obtain MAX RPM)

### **CRUISE**

1. Power - 2100-2700 RPM (no more than 75% is recommended)
2. Elevator Trim - Adjust
3. Mixture - LEAN

### **DESCENT**

1. Power - AS DESIRED
2. Mixture - ADJUST for smooth operation
3. Fuel Selector Valve - BOTH

## **BEFORE LANDING**

1. Pilot and Passenger Seat Backs - MOST UPRIGHT POSITION
2. Seat and Seat Belts - SECURE and LOCKED
3. Fuel Selector - BOTH
4. Undercarriage - CHECK
5. Mixture - RICH
6. Landing/Taxi Lights - ON
7. Autopilot (if installed) - OFF

## **LANDING**

### **Normal Landing**

1. Airspeed - 65-75 KIAS (Flaps UP)
2. Wing Flaps - AS DESIRED (0°-10° below 110 KIAS, 10°-30° below 85 KIAS)
3. Airspeed – 60-70 KIAS (Flaps DOWN)
4. Touchdown - MAIN WHEELS FIRST
5. Landing Roll - LOWER NOSE WHEEL GENTLY
6. Braking - MINIMUM REQUIRED

### **Short Field Landing**

1. Airspeed - 65-75 KIAS (Flaps UP)
2. Wing Flaps - FULL DOWN (0°-10° below 110 KIAS, 10°-30° below 85 KIAS)
3. Airspeed - 61 KIAS (until flare)
4. Power - REDUCE to Idle after clearing obstacle)
5. Touchdown - MAIN WHEELS FIRST
6. Brakes - APPLY HEAVILY
7. Wing Flaps - RETRACT

## **Balked Landing**

1. Throttle - FULL OPEN
2. Wing Flaps - Retract to 20°
3. Climb Speed - 60 KIAS
4. Wing Flaps - 10° (until obstacles are cleared). RETRACT (after reaching a safe altitude and 65 KIAS)

## **AFTER LANDING**

1. Wing Flaps - UP
2. Transponder - STBY
3. Nav, Strobe, Pulse Lights – AS REQUIRED
4. Engine – LEAN for Taxi

## **SECURING AIRPLANE**

1. Parking brake - SET
2. Avionics Master Switch, Electrical Equipment, Autopilot (if installed) - OFF
3. Throttle – 1000 RPM
4. Mixture - IDLE CUT-OFF (pull full out)
5. Throttle - IDLE
4. Ignition Switch - OFF
5. Master Switch - OFF
6. Fuel Selector Valve - RIGHT
7. Avionics Control Lock - INSTALL
8. Pitot Tube Cover - INSTALL
9. Aircraft Doors and Baggage Compartment – LOCK with Key

# EMERGENCY CHECKLIST

## ENGINE FAILURES

### ENGINE FAILURE DURING TAKEOFF ROLL

1. **THROTTLE - IDLE**
2. **BRAKES - APPLY**
3. Wing Flaps - RETRACT
4. Mixture - IDLE CUT-OFF
5. Ignition Switch - OFF
6. Master Switch - OFF

### ENGINE FAILURE IMMEDIATELY AFTER TAKEOFF

1. **AIRSPEED - 70 KIAS (FLAPS UP)**  
**65 KIAS (FLAPS DOWN)**
2. Mixture - IDLE CUT-OFF
3. Fuel Shutoff Valve - OFF (Pull full out)
4. Ignition Switch - OFF
5. Wing Flaps - AS REQUIRED
6. Master Switch - OFF
7. Cabin Door - UNLATCHED
8. Land - STRAIGHT AHEAD

### ENGINE FAILURE DURING FLIGHT (RESTART PROCEDURES)

1. **AIRSPEED - 68 KIAS**
2. **FUEL SHUTOFF VALVE - IN (PUSH FULL IN)**
3. **FUEL SELECTOR VALVE - BOTH**
4. **AUXILIARY FUEL PUMP SWITCH - ON**
5. **MIXTURE - RICH (IF RESTART HAS NOT OCCURRED)**
6. Ignition Switch - BOTH (or START if propeller is stopped)

## FORCED LANDINGS

### EMERGENCY LANDING WITHOUT ENGINE POWER

1. Passenger Seat Backs - MOST UPRIGHT POSITION
2. Seat and Seat Belts - SECURE
3. AIRSPEED - 70 KIAS (Flaps UP)  
65 KIAS (Flaps DOWN)
4. Mixture - IDLE CUT-OFF
5. Fuel Shutoff Valve - OFF (Pull full out)
6. Ignition Switch - OFF
7. Wing Flaps - AS REQUIRED (30° recommended)
8. Master Switch - OFF (when landing is assured)
9. Doors - UNLATCH PRIOR TO TOUCHDOWN
10. Touchdown - SLIGHTLY TAIL LOW
11. Brakes - APPLY HEAVILY

### PRECAUTIONARY LANDING WITH ENGINE POWER

1. Passenger Seat Backs - MOST UPRIGHT POSITION
2. Seat and Seat Belts - SECURE
3. Airspeed - 65 KIAS
4. Wing Flaps - 20°
5. Selected Field - FLY OVER, noting terrain and obstructions, then retract flaps upon reaching a safe altitude and airspeed
6. Avionics Master Switch and Electrical Switches - OFF
7. Wing Flaps - 30° (on final approach)
8. Airspeed - 65 KIAS
9. Master Switch - OFF
10. Doors - UNLATCH PRIOR TO TOUCHDOWN
11. Touchdown - SLIGHTLY TAIL LOW
12. Ignition Switch - OFF
13. Brakes - APPLY HEAVILY

### DITCHING

1. Radio - TRANSMIT MAYDAY on 121.5, giving location and intentions and SQUAWK 7700

2. Heavy Objects (in baggage area) - SECURE or JETTISON
3. Passenger Seat Backs - MOST UPRIGHT POSITION
4. Seat and Seat Belts - SECURE
5. Wing Flaps - 20° to 30°
6. Power - ESTABLISH 300 FT/MIN DESCENT AT 55 KIAS

### **NOTE**

If no power is available, approach at 65 KIAS with flaps up or at 60 KIAS with 10° Flaps

7. Approach - High Winds, Heavy Seas - INTO THE WIND  
Light Winds, Heavy Swells - PARALLEL TO SWELLS
8. Cabin Doors - UNLATCH
9. Touchdown - LEVEL ATTITUDE AT ESTABLISHED RATE OF DESCENT
10. Face - CUSHION at touchdown with folded coat
11. ELT - ACTIVATE
12. Airplane - EVACUATE through cabin doors. If necessary, open window and flood cabin to equalize pressure so doors can be opened
13. Life Vests and Raft – INFLATE WHEN CLEAR OF AIRPLANE

## **FIRES**

### **DURING START ON GROUND**

1. **CRANKING - CONTINUE** to get a start which would suck the flames and accumulated fuel through the carburetor and into the engine.

If the engine starts:

2. Power - 1800 RPM for a few minutes
3. Engine - SHUTDOWN and inspect for damage

If engine fails to start:

4. **THROTTLE - FULL OPEN**

5. **MIXTURE - IDLE CUT-OFF**
6. **CRANKING - CONTINUE**
7. **FUEL SHUTOFF VALVE - OFF (PULL FULL OUT)**
8. **AUXILIARY FUEL PUMP - OFF**
9. Fire Extinguisher - ACTIVATE
10. Engine - SECURE
  - a. Master Switch - OFF
  - b. Ignition Switch - OFF
11. Parking Brake - RELEASE
12. Airplane - EVACUATE
13. Fire - EXTINGUISH using fire extinguisher, wool blanket, or dirt
14. Fire Damage – INSPECT

### **ENGINE FIRE IN FLIGHT**

1. **MIXTURE - IDLE CUT-OFF**
2. **FUEL SHUTOFF VALVE - OFF (PULL FULL OUT)**
3. **AUXILIARY FUEL PUMP - OFF**
4. **MASTER SWITCH - OFF**
5. Cabin Heat and Air - OFF (except overhead vents)
6. Airspeed - 100 KIAS (If fire is not extinguished, increase glide speed to find an airspeed - within airspeed limitations - which will provide an incombustible mixture)
7. Forced Landing - EXECUTE (as described in Emergency Landing Without Engine Power)

### **ELECTRICAL FIRE IN FLIGHT**

1. **MASTER SWITCH - OFF**
2. **VENTS/CABIN AIR/HEAT - CLOSED**
3. **FIRE EXTINGUISHER – ACTIVATE**
4. Avionics Master Switch - OFF
5. All Other Switches (except ignition switch) - OFF

### **WARNING**

**AFTER DISCHARGING FIRE EXTINGUISHER AND ASCERTAINING THAT FIRE HAS BEEN EXTINGUISHED, VENTILATE THE CABIN**

6. Vents/Cabin Air/Cabin Heat – OPEN when it is ascertained that the fire is completely extinguished

If fire has been extinguished and electrical power is necessary for continuance of flight to nearest airport or landing area:

7. Master Switch - ON
8. Circuit Breakers - CHECK for faulty circuit, do not reset
9. Radio Switches - OFF
10. Avionics Master Switch - ON
11. Radio/Electrical Switches - ON one at a time, with delay after each until short circuit is localized

### **CABIN FIRE**

1. **MASTER SWITCH - OFF**
2. **VENTS/CABIN AIR/HEAT - CLOSED**
3. **FIRE EXTINGUISHER - ACTIVATE**

### **WARNING**

**AFTER DISCHARGING FIRE EXTINGUISHER AND ASCERTAINING THAT FIRE HAS BEEN EXTINGUISHED, VENTILATE THE CABIN**

4. Vents/Cabin Air/Cabin Heat – OPEN when it is ascertained that the fire is completely extinguished
5. Land the airplane as soon as possible to inspect for damage

### **WING FIRE**

1. **LANDING/TAXI LIGHT SWITCHES - OFF**
2. **NAVIGATION LIGHT SWITCH - OFF**
3. **STROBE LIGHT SWITCH - OFF**
4. **PITOT HEAT SWITCH - OFF**

### **NOTE**

Perform a sideslip to keep the flames away from the fuel tank and cabin. Land as soon as possible using flaps only as required for final approach and touchdown

## **ICING**

### **INADVERTENT ICING ENCOUNTER**

1. **TURN PITOT HEAT SWITCH ON**
2. **TURN BACK OR CHANGE ALTITUDE** to obtain an outside air temperature that is less conducive to icing
3. **PULL CABIN HEAT CONTROL FULL OUT AND OPEN DEFROSTER OULETS** to obtain maximum windshield defroster airflow. Adjust cabin air control to get maximum defroster heat and airflow
4. Watch for signs of engine-related icing conditions. An unexplained loss in engine speed could be caused by ice blocking the air intake filter, or in extremely rare instances, ice completely blocking the fuel injection air reference tubes. Change the throttle position to obtain maximum RPM. This may require to either advancing or retarding the throttle, dependent on where ice has accumulated in the system. Adjust mixture, as required, for maximum RPM
5. Plan a landing at the nearest airport. With an extremely rapid ice build-up, select a suitable “off airport” landing site
6. With an ice accumulation of 1/4 inch or more on the wing leading edges, be prepared for significantly higher stall speed
7. Leave wing flaps retracted. With a severe ice build-up on the horizontal tail, the change in wing wake airflow direction caused by wing flap extension could result in a loss of elevator effectiveness
8. Open left window and, if practical, scrape ice from the portion of the windshield for visibility in the landing approach
9. Perform a landing approach using a forward slip, if necessary, for improved visibility
10. Approach at 65 to 75 KIAS depending upon the amount of the accumulation



11. Perform a landing in level attitude

### **STATIC SOURCE BLOCKAGE (Erroneous Instrument Reading Suspected)**

1. **STATIC PRESSURE ALTERNATE SOURCE VALVE - PULL ON**
2. Airspeed - Consult appropriate calibration tables in section 5

### **LANDING WITH A FLAT MAIN TIRE**

1. Approach - NORMAL
2. Wing Flaps - 30°
3. Touchdown - GOOD TIRE FIRST, hold airplane off flat tire as long as possible with aileron control
4. Directional Control - MAINTAIN using brake on good wheel as required

### **LANDING WITH A FLAT NOSE TIRE**

1. Approach - NORMAL
2. Flaps - As required
3. Touchdown - ON MAINS, hold nose wheel off the ground as long as possible
4. When nose wheel touches down, maintain full up elevator as airplane slows to stop

## **ELECTRICAL POWER SUPPLY SYSTEM MALFUNCTIONS**

### **AMMETER SHOWS EXCESSIVE RATE OF CHARGE (Full Scale Deflection)**

1. Alternator - OFF

### **CAUTION**

**WITH THE ALTERNATOR SIDE OF THE MASTER SWITCH OFF, COMPASS DEVIATIONS OF AS MUCH AS 25° MAY OCCUR**

2. Nonessential Electrical Equipment - OFF
3. Flight - TERMINATE as soon as practical

### **LOW-VOLTAGE ANNUNCIATOR (VOLTS) ILLUMINATES DURING FLIGHT (Ammeter Indicates Discharge)**

#### **NOTE**

Illumination of "VOLTS" on the annunciator panel may occur during low RPM conditions with an electrical load on the system such as during a low RPM taxi. Under these conditions, the light will go out at higher RPM. The master switch need not be recycled since an overvoltage condition has not occurred to deactivate the alternator system

1. Avionics Master Switch - OFF
2. Alternator Circuit Breaker – CHECK IN
3. Master Switch - OFF (both sides)
4. Master Switch - ON
5. Low Voltage Annunciator - CHECK OFF
6. Avionics Master Switch - ON

If Low-Voltage Light illuminates again:

7. Alternator - OFF

### **CAUTION**

**WITH THE ALTERNATOR SIDE OF THE MASTER SWITCH OFF, COMPASS DEVIATIONS OF AS MUCH AS 25° MAY OCCUR**

8. Nonessential Radio and Electrical Equipment - OFF
9. Flight - TERMINATE as soon as practical

## **VACCUM SYSTEM FAILURE**

Left Vaccum or Right Vaccum Annunciator light (L VAC R) illuminates

### **CAUTION**

**IF VACCUM IS NOT WITHIN NORMAL OPERATING LIMITS, A FAILURE HAS OCCURRED IN THE VACCUM SYSTEM AND PARTIAL PANEL PROCEDURES MAY BE REQUIRED FOR CONTINUED FLIGHT**

1. **VACCUM GAUGE - CHECK** to ensure vaccum within normal operating limits